

Operation Guide

How to install Automatic Sanitizer Dispenser?

1. Select a suitable place where the machine can be wall-mounted, generally, it is nearby to the entrance.
2. Make sure that the selected place should not be overcrowded.
3. Open a corrugated packing box that contents a dispenser set, power plug, and installation guide manual.
4. This device is easy to hang on the wall, so make arrangements accordingly.
5. Once it is wall-mounted, plug the power cord to the 6A socket.
6. It is always advisable to mount it away from the children's reach.
7. The inlet for the sanitizer addition is at the top, so pour it in the tank until it gets filled.
8. During sanitization liquid addition, make sure that the liquid should not be overflow.
9. Then switched ON the devices and made sure that the LED indication is working.
10. Now the system is ready to dispense the sanitizer as per the hand motion.
11. Once you take your palm below the nozzle, instantly, the mist of sanitization liquid comes out.
12. That means the installation is successful.

How to refill the Dispenser tank?

1. The level indication marks given to identify the amount of liquid present in the tank.
2. The outer body of the device consists of a transparent wall, which used to indicate the sanitizing liquid level in the tank.
3. Once it is completely drained, the next batch of the exact amount of sanitizer should be poured into the tank.
4. The process of refilling is easy since there is only an adding of liquid without opening of dispenser.

Techinstro assures the above specification and dimensions of the product as per the datasheet. We ensure the quality of the product with moisture-proof packing. This sheet is also available on the website, where the researcher or purchaser can also download it merely by clicking on the pdf link. The terms and conditions for the product purchase mentioned in the quotation. For safe product storage, tips, and procedures provided with the material. For more queries, contact our technical support.